- Welcome to the Sani Station -

Disposal of stationary and portable tanks

- 1.) Insert coin
- 2.) Press the button with the symbol (If you choose the wrong program, press the STOP button and make a new selection)
- 3.) Press the OK button to confirm selection
 - The sliding shutter will open for approximately 4,5 minutes.
- 4.) Place the waste hose into the basin or pour out the portable tank
 - The basin will be rinsed automatically
- 5.) To clean the tank press the button inside the basin and use the water run-out
- 6.) End disposal at the sound of the warning signal
 - The sliding shutter will close
 - Do not block the sliding shutter

Withdrawing fresh water

- 1.) Insert coin
- 2.) Attatch supply hose to the water faucet beside the control panel and open the faucet
- 3.) Press the button with the symbol (If you choose the wrong program, press the STOP button and make a new selection)
- 4.) Press the OK button to confirm selection
 - Fresh water will run for 5 minutes
 - The red STOP button will end the water supply
- 5.) Close the faucet and remove the hose

Warning

Both programs cannot be used simultaneously. Wait until the current program has ended before inserting coins for the next program.

- We wish you a good trip -